



WARNING!

Liebert FH125A-A10 Cooling System shuts off when the outside temperature exceeds $\sim 37^{\circ}\text{C}$. After the temperature has fallen below this threshold again, the system needs to be restarted.

Symptoms:

- Outside temperature exceeds $\sim 37^{\circ}\text{C}$.
- Event Log displays Compressor 1 & 2 high pressure alarm
- An alarm tone sounds

How to fix it:

- Press Button 1 to silence alarm tone

Once the temperature has fallen below the 37°C threshold:

- Turn off system using button 2
- Restart using the Power Switch
- Wait 60s
- Restart using Button 2



Power Switch

