

Rim Wiring Schedule						
Reference: alidadeWireHarness.xls						
Reference: datasheet-PAX.doc						
Reference: frontendWiring.xls						
5/31/2006						
RP1	Cable from Rim box to PAC (PAX Case)			Belden 8170 (S) - Belden 1037A (P)		
A,B	Description		Size	Color	Twist	Length
A	TEC power		#16	P-B1	Z	54"
B	TEC power		#16	P-W1	Z	
C	Shield		#18	P-S1	-	
D	dewar diode 1		#24	S-BF-Red	Y	
E	dewar diode 2		#24	S-BF-Blu	Y	
F	SPARE		#16	P-B3	X	
G	SPARE		#16	P-W3	X	
H	SPARE		#24	S-BF-Br	W	
J	SPARE		#24	S-BF-Blk	W	
K	compressor power		#16	P-B2	V	
L	compressor power		#16	P-W2	V	
M	Shield		#18	P-S2	-	
N	cryocooler therm 2		#24	S-BF-Red	U	
P	cryocooler therm 1		#24	S-BF-Gr	U	
R	-6V (OTX/PAM)		#24	S-GF-Blu	T	
S	GND		#24	S-GF-Blk	T	
T	PAXTEC therm 1		#24	S-BF-Red	S	
U	PAXTEC therm 2		#24	S-BF-Wh	S	
V	GNDsense		#24	S-RF-Blk	R	
W	+6sense		#24	S-RF-Gr	R	
X	+5sense		#24	S-GF-Wh	Q	
Y	-6sense		#24	S-GF-Blk	Q	
Z	+5V (OTXTEC)		#24	S-RF-Red	P	
a	GND		#24	S-RF-Blk	P	
b	GND		#24	S-BF-Blk	O	
c	+6V (OTXlaser/PAM)		#24	S-BF-Y	O	
d	GND		#24	S-BF-Blk	M	
e	+5V (OTXTEC)		#24	S-BF-Or	M	
A	UTG620-28SN	#16/#18 get RM16M23D28 pins	UTG20ACN housing			
B	UTG620-28SN	#24 get SM24ML1D70 pins				

RW1 Cable inside rim box from bottom connector to components for RP1							
A	Description	B,C,D,E,F,G	Size	Color	Twist	Length	Comment
A	TEC power		#16				
B	TEC power		#16				
C	Shield		#18				
D	dewar diode 1		#24				
E	dewar diode 2		#24				
F	SPARE		#16				
G	SPARE		#16				
H	SPARE		#24				
J	SPARE		#24				
K	compressor power		#16				
L	compressor power		#16				
M	Shield		#18				
N	cryocooler therm 2		#24				
P	cryocooler therm 1		#24				
R	-6V (OTX/PAM)		#24				
S	GND		#24				
T	PAXTEC therm 1		#24				
U	PAXTEC therm 2		#24				
V	GNDsense		#24				
W	+6sense		#24				
X	+5sense		#24				
Y	-6sense		#24				
Z	+5V (OTXTEC)		#24				
a	GND		#24				
b	GND		#24				
c	+6V (OTXlaser/PAM)		#24				
d	GND		#24				
e	+5V (OTXTEC)		#24				
A	UTC020-28P	#16/#18 get RC16M23D28, #24 get SC24ML1D70 sockets					
B							
C							
D							
E							
F							
G							
RW2 24V from power supply to STI supply							
A, B	Description		Size	Color	Twist	Length	Comment
1							
2							
A	Tyco 1-480698(newark 46F2063) with 2 contacts Tyco 350550-2(Newark 90F5656)						
B	Tyco 1-480698(newark 46F2063) with 2 contacts Tyco 350550-2(Newark 90F5656)						

++++RimWiring++++

RW3 serial from STI to ucnlr							
A,B	Description		Size	Color	Twist	Length	Comment
1							
2							
3							
A							
B							
RW4 from TEC to ucnlr							
A	Description	B	Size	Color	Twist	Length	Comment
A							
B							
RW5 24V from power supply to TEC board							
A	Description	B	Size	Color	Twist	Length	
RW6 connection from power mgmt board to control board							
A	Description	B	Size	Color	Twist	Length	
RW7 connection from power mgmt board to control board							
A	Description	B	Size	Color	Twist	Length	
1							
2							
3							
4							
5							
RF1 Cable from rim to feed focus drive Belden 9943							
A	Description	B	Size	Color	Twist	Length	
1	Motor		#22	red		58"	
2	Motor			white			
3	Motor			black			
4	Extend stop			orange			
5	Common			brown			
6	retract stop			blue			
7	ground			green			
A		Rim box end	13/16" strip back on connector			3/8" strip on shield	
B		Terminal end	5" strip back on jacket/shield			green #6 spade	

++++RimWiring++++

